

Dear User,

We congratulate you on buying the product. We are pleased you have chosen to buy one of our strollers and we hope you will use it with satisfaction. We advise you to read the manual carefully before use and keep it in a safe place for future use. Please pay attention to our directions for use of the stroller, which will allow you long and unproblematic use.

CAMARELO

Directions for use

– Read the manual before use and keep it for future use. The safety of your child may be endangered if you do not act according to the recommendations.

1. The materials used for production are certified. However, we advise you not to leave the stroller exposed to sunshine for a long time. The fading of colours will not be subject to warranty. The material should be cleaned manually in cold or lukewarm water with the use of gentle washing powder. Do not wash in a washing machine!
2. The stroller has been produced according to the European norm EN 1888:2012 and ISO 9001:2000. To prolong the time of use of the product all mobile parts should be lubricated regularly (including axis and bearings). Attention: for lubrication use only silicone lubricant or silicone spray
3. Make sure the place you are going to store the stroller is safe to protect the stroller from being wet or broken.
4. Regular maintenance affect the safety of your child and prolong the durability. Salty air, industrial salt, acid rain can cause corrosion. Therefore, we suggest you to keep the stroller inside. Do not storage stroller in humid and cold places
5. We suggest regular maintenance of frame and wheels. To clean use only a cloth and water with soft detergent.
6. Do not store things on a folded pram to avoid damage.
7. Replace broken or damaged parts immediately.
8. Air pressure in wheels should not exceed 0.5 bar.

Acting according to the directions will insure long and satisfactory use of the product.

Useful information concerning safety:

1. The stroller may collapse if you place things on the hood or handle.
2. Make sure the child does not play near the stroller.
3. Leaving the stroller make sure you used the brake.
4. Do not leave the stroller and your child in the stroller unattended.
5. Make sure the harness is properly buckled.
6. Always use the brake while not moving.
7. Make sure the stroller is properly assembled before you place the child in it. Attention: too much weight may cause danger.
8. Make sure you use the stroller properly.
9. The maximum weight for the carrycot is 9 kg.
10. The maximum weight for the shopping basket: 2 kg.
11. Do not let the stroller to be wet - always use raincover while it is raining.
12. The seat unit is designed for children over 6 months and up to 15 kg. The carrycot is appropriate from the first days of life.
13. The product has been certified according to the European norm EN 1888:2012 and ISO 9001:2000.
14. Do not use any manuals different than the one attached to Camarelo products.
15. Always place the stroller on a sidewalk or other safe place while folding the frame.

WARNINGS

- Block all mechanisms before use.
- Do not hang and additional balast on a handle.
- Seat unit is not appropriate for children under 6 months old.
- Always use the shoulder and crotch seatbelts when using the seat unit.
- Leaving a child unattended can be dangerous for them.
- Do not use a mattress thicker than 10 mm.
- Do not use an additional mattress.
- Do not let the baby stand in a stroller or sit without fastened seatbelts.
- Make sure the carrycot/seat unit/car seat are properly assembled before use.
- The stroller may not be used when running or skating.
- The stroller may be used by ONE child at a time.
- Do not carry a carrycot with a baby inside!**
- Do not swing the stroller sideways!**
- Do not go with a stroller up and down the stairs. The stroller should be carried without a baby inside.**
- Always lift the suspension up when moving forward a kerb or other obstacle.

Do not use additional equipment not mentioned by the manufacturer. The manufacturer will not be responsible for the effects of inappropriate use of the stroller.

CAMARELO
www.camarelo.eu



Manual
READ CAREFULLY BEFORE USE
AND KEEP THE MANUAL FOR
FUTURE USE

Baleo



WARRANTY CARD

Product type

Date of sell



Stamp and signature of seller

I acknowledge the terms and conditions of warranty.

..... Client's signature

Produced by:
CAMARELO s.c.
42-215 Częstochowa ul. Młodości 14, tel.: +48 34 3225464
e-mail: biuro@camarelo.pl

Terms and Conditions

12-month guarantee, from the date of purchase.
The seller determines terms and conditions of the warranty repairs.

Warranty does not include:

- damages caused by use which is not in agreement with the manual,
- mechanical and thermal damages,
- peculiar processing and fixing done by third party,
- damages caused in accidents,
- everyday expenditure, e.g wheels, inner tubes, tyres or material fading.

In the event of defects please contact the seller immediately. When defects occur in a product which was bought through the Internet please contact the seller or distributor.

If the seller cannot remove the defect, the product should be sent to the manufacturer together with the Warranty and a description of the defect.

Please do not send the product at the expense of the manufacturer. The repair will be done in the shortest possible time. The warranty will be prolonged by the time of the repair.

Damages caused by user will be removed at their expense. No duplicates of warranty will be given.

Only clean products will be accepted for guarantee repairs!!!

No.	Date of notification	Date of implementation	Description	Signature

1. Folded chassis.
2. Unfolded chassis.
3. Before folding please remove the carrycot/seat unit/car seat. To fold the chassis move both handles upwards at the same time and pull the frame downwards. Handle height adjustment. Push the buttons (1) placed on the both sides of the handle and while holding them put the handle into desired position.
4. Assembly of front wheel. Move the chassis upwards and place the axis in the hub. Dismantle of front wheel. Move the chassis upwards, press the button (1) and slide out of the hub.
5. Blocking of front wheels. Twist the ring (1) right to block the wheel. Unblocking front wheels. Twist the ring left (1) for the wheel to turn.
6. Assembly of rear wheels. To assemble rear wheels, slide the hub on the axis (1) holding the protection at the same time (2) until the wheel is blocked on the axis. Dismantle of rear wheels. Press and hold the protection (2) and release the wheel from the hub.
7. Rear wheel brake. To block the rear wheel stamp on the brake (1). By moving the brake upwards you release the brake.
8. Carrycot. Remove the mattress and the metal enhancers(1), next (2) move them into the guides until locked. Make sure they have been properly locked.
9. Assembly of a carrycot backrest regulation. Place the metal rod (1) into the slot in a regulation mechanism (2).
10. Decide on the height of the seat (3), place the mattress. Unfold the hood.
11. To fold the hood press and hold the buttons (1) and fold the hood. Placing the carrycot liner. To attach the carrycot liner, place it on the carrycot (2) and press the side buttons (3).
12. Assembly of carrycot/seat unit. To put the carrycot on the chassis place it in appropriate mounts (1) on each side of the pram (1). The carrycot will block automatically.
13. Release of carrycot/seat unit. To release the carrycot push the buttons (1). Repeat on the other side of the pram. Next move the carrycot/seat unit upwards and remove from the mounts.
14. Assembly/release of the car seat adapters. The car seat adapter allows to install the car seat on the chassis. Place the adapters (1) appropriately on both sides of the pram. To release the adapters push the buttons (2) on both sides of the car seat. The car seat with the adapters can be attached to the chassis according to points 13,14 (assembly/dismantle of carrycot/seat unit). The car seat is an OPTION.
15. Handlebar. The handlebar can be attached by inserting the hooks (1) on both sides of the pram (2). To remove the handlebar it needs to be unhooked. Remember to buckle up the harness every time you remove the handlebar.
16. Footrest. To adjust the footrest push the buttons simultaneously (1) and place the footrest in the desired position.
17. 4 position seat unit. The back in a seat unit can be positioned by pulling up the lever and moving the back into desired position (1).
18. Hood. To remove the hood press the buttons on both sides of the stroller (1) and pull it upwards. To assemble the hood insert the hooks (2) on both sides of the stroller. To position the hood you push it back or pull it to the front.
19. 5-point harness. To buckle up the harness you push the sides of the buckle (2) and slide it in the hook (1). To open the harness you press the side of the buckle (3) (2) and slide it out of the hook (1).

Features: chassis, swivel wheels, carrycot with mattress and footmuff, seat unit with footmuff and handle bar , bag (attached to the stroller handle), rain-cover, warranty and manual.

